



The self-ventilating facade




Air is pulled into the construction through an opening at the base of the facade. Unobstructed ventilation must be ensured throughout the facade's height. The ventilated area behind the boards must be at least 20mm. There must be a min. ventilation gap of 10mm or 100cm² per meter at openings.

Screw and batten distances




Max. support distance: 629mm o.c.
 Max. screw/revet distance: 600mm o.c.
 Max. wind load: please find the wind load table in the global Cembrit Construction installation manual found on cembrit.com.

Distances on wood








Fixing distances from the top of the board should be min. 100mm and max. 150mm. Fixing distances from the side of the board should be min. 25mm and max. 150mm.


Distances on steel/aluminium



Fixing distances from the top of the board should be min. 100mm and max. 150mm. Fixing distances from the side of the board should be min. 30mm and max. 150mm.



Wood structure



Batten width should be min. 100mm for supporting battens and 45mm for central battens. When using timber battens, always use Cembrit EPDM with profiled ribs.

Screw: pre-drilling with $\varnothing 8\text{mm}$



Applying Cembrit Facade Screws. Ensure that the screws are centrally located in pre-drilled holes. Please be careful not to overtighten the screw - especially near the edges and corners of the boards.



When using fixing points for wood the hole diameter should be $\varnothing 5\text{mm}$.



Cembrit Facade Screw
SCR-W 4.5x30 /36 /41mm
12mm head




Cembrit Facade Wing Screw
SCR-W W 4.9x38mm
12mm head



Cembrit EPDM 3x50/100mm



Steel profiles



Cembrit recommends that the steel has a min. thickness of 0.7mm. The max. length of the steel profile is 3000mm. The profiles behind joints should have a min width of 100mm, and the middle profiles should have a min. width of 40mm. Always use flat EPTL/EPDM on steel profiles.


Screw: pre-drilling with $\varnothing 8\text{mm}$
Rivet: pre-drilling in facade board with $\varnothing 9\text{mm}$ and in steel with $\varnothing 4.8\text{mm}$



Applying Cembrit Facade Screws. Ensure that the screws are centrally located in pre-drilled holes. Please be careful not to overtighten the screw - especially near the edges and corners of the boards.



Rivet - Fixing point hole diameter $\varnothing 9\text{mm}$. Insert a Cembrit Fixing Sleeve in the hole before the rivet is fixed.



Screw - Fixing point hole diameter $\varnothing 5\text{mm}$.




Cembrit Facade Screw Steel
SCR-S 4.8x29mm
12mm head



Cembrit Rivet Steel
4.8x20mm



Aluminium profiles



Cembrit recommends that the aluminium is of minimum 1.8mm thickness. Maximum steel profile length is 3000mm. T profiles behind joints should be min 100mm width, and the L profiles should be min 40mm width. Always use flat EPTL/EPDM on aluminium profiles.

Rivet: pre-drilling in facade board with $\varnothing 9\text{mm}$ and in aluminium with $\varnothing 4.1\text{mm}$



Rivet - Fixing point hole diameter $\varnothing 9\text{mm}$. Insert a Cembrit Fixing Sleeve in the hole before the rivet is fixed.



Cembrit Rivet Steel
4.0x20mm




The Stand-Off Head must be used for all rivets. This provides a small space between the board and the rivet head to allow for movement caused by moisture or temperature changes.



All

Facade boards must be installed using two fixing points*. These should be as close to the board center as possible and must be aligned horizontally.


*Optional for wood



To ensure a neat finish when cutting Cembrit Construction boards, it is important to use the correct blade. Contact your local Cembrit office for more information. Never use water when cutting Cembrit facade boards.



Cembrit Construction boards should NOT be sealed with Cembrit Edge Sealer.



Remove dust and gravel from the board after cutting or drilling the board.



As with all building materials, safety precautions must be taken into account and local laws and regulations must be observed.



For more information go to www.cembrit.com

CEMBRIT